




LSM-S

TV LIFT AND SWIVEL



INSTALLATION INSTRUCTIONS

ISSUE 004

SAFETY DISCLAIMER

IMPORTANT SAFETY INSTRUCTIONS BELOW

WARNING: Failure to provide adequate structural strengthening, prior to installation can result in serious personal injury or damage to the equipment. It is the installer's responsibility to ensure the structure to which the component is affixed can support four times the weight of the component and any additional apparatus mounted to the component.

WARNING: Do not exceed the weight capacity for this product as listed below. This can result in serious personal injury or damage to the equipment. It is the installer's responsibility to ensure that the total combined weight of all attached components does not exceed that of the maximum figure stated.

WARNING: Risk of death or serious injury may occur when children climb on audio and/or video equipment or furniture. A remote control or toys placed on the furnishing may encourage a child to climb on the furnishing and as a result the furnishing may tip over on to the child.

WARNING: Risk of death or serious injury may occur. Relocating audio and/or video equipment to furniture not specifically designed to support audio and/or video equipment may result in death or serious injury due to the furnishing collapsing or over turning onto a child or adult.



Only for use with equipment weighing **110LBS (50KG) OR LESS.**

Use with heavier projectors/equipment may lead to instability causing tip over or failure resulting in death or serious injury.

Bracket Suitable for Residential and Commercial Use.

ADDITIONAL WARNINGS:

1. Keep all documentation/instructions after fitting.
2. Read all technical instructions fully before installation and use. It is the installer's responsibility to ensure that all documentation is passed on to the end user and read fully before operation.
3. Do not use near water or outdoors unless the product has been specifically designed to do so.
4. Protect any cables or cords being used near this bracket from being walked on or pinched to prevent damage and risk of injury.
5. Use this product only for its intended purpose as described in the product instructions and only use attachments/ accessories specified by the manufacturer.
6. Do not operate the product if it is damaged in any way, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped. Contact the original installer/manufacturer to arrange repair or return.

WARNING - To reduce the risk of burns, fire, electric shock, or injury to persons:

1. Clean only with a dry cloth and always unplug any electrical items being used in conjunction with this product before cleaning.

Future Sound & Vision trading as Future Automation intend to make this and all documentation as accurate as possible. However, Future Automation makes no claim that the information contained herein covers all details, conditions or variations, nor does it provide for every possible contingency in connection with the installation or use of this product. The information contained in this document is subject to change without prior notice or obligation of any kind. Future Automation makes no representation of warranty, expressed or implied, regarding the information contained herein. Future Automation assumes no responsibility for accuracy, completeness or sufficiency of the information contained in this document.

PRODUCT WARRANTY & RISK ASSESSMENT

WARRANTY INFORMATION

WARNING - The warranty offered for this product shall be annulled if the product is used improperly or in a way that is in breach of our Terms of Service.

Future Automation provides warranty for the mechanism you purchased for the period of **24 months** from the date of purchase, provided that it isn't used for unintended purposes.

Under the warranty, Future Automation aims to either solve the issue remotely (via telephone or email support) or if the mechanism requires a part, arrange a visit to your premises by a Future Automation approved engineer or send replacement items where appropriate.

Warranty repairs will be carried out as quickly as possible, but subject to parts availability. This warranty period is respectively extended for the period of a repair.

A malfunctioning product must be cleaned and placed into suitable packaging to protect against transit damage before organising delivery to a repair workshop.

All the complaints about defects must be submitted to the vendor/installer that sold this product, rather than directly to the manufacturer.

Any part of your system that needs to be replaced during a warranty repair becomes the property of Future Automation.

The warranty does not cover the following:

- Damages resulting from improper product use or maintenance.
- Repairs carried out by unauthorized persons.
- Natural wear and tear during operation.
- Damages caused by the buyer.
- Accidental damages caused by a customer or damages caused as a result of careless attitude or usage, or damages caused by natural disasters (natural phenomena).
- Any electrical, or other environmental work external to your Future Automation mechanism including power cuts, surges etc.
- Additional items not supplied by Future Automation although they may have been supplied together by the retailer
- Any 3rd party software products controlling your mechanism
- Any transfer of ownership. Warranty is provided only to the initial purchaser.
- Compensation for loss of use of the product, and consequential loss of any kind.

A separate Safety and Servicing Information document is provided with these instructions (additional copies can be found at www.futureautomation.co.uk/safety), and this document **MUST** be filled out by the approved Future Automation Dealer who is installing the product. This Warranty Sheet must be held by the end user for the duration of the products life and will be referred to during servicing or warranty queries.

The Safety and Servicing Information document also contains two Service History Forms that must be filled in by the approved Future Automation dealer who is performing the first required yearly service of this product.

One copy of the Service History Form must be held by the customer (along with the Warranty Sheet) and a duplicate copy must be held by the approved Future Automation dealer that performed the service. Missing and/or mismatching documents may delay or invalidate warranty claims.

Additional Service History Forms can be found on the Future Automation website for further yearly services.

RISK ASSESSMENT INFORMATION

It is the installer's responsibility to perform a risk assessment of installed products. Future Automation can provide guidelines to installers/dealer about what should be included in a risk assessment, but due to the individual nuances of each location/site, Future Automation cannot provide a full list of areas to risk assess.

For full risk assessment and safety information please view our Safety and Servicing guide available at www.futureautomation.net/safety

GUIDE CONTENTS

SAFETY DISCLAIMER	1
PRODUCT WARRANTY & RISK ASSESSMENT	2
GUIDE CONTENTS	3
PACKAGE CONTENTS	4
MECHANISM QUICK-START GUIDE	5
INITIAL OPERATION	6
CABINET MOUNTING	7
LSM-BE MOUNT ASSEMBLY	8
BOX ENCLOSURE FIXING	9
BOX ENCLOSURE AND BASE PANEL FIXING	10
BOX ENCLOSURE FIXING	11
BOX ENCLOSURE ADJUSTMENT	11
SCREEN MOUNTING	12
SWITCH ADJUSTMENTS	13
CABLE ROUTING	14
CONTROLLING MECHANISM	15
GENERAL CONTROL	16
INFRARED (IR)	17
RADIO FREQUENCY (RF)	18
CONTACT CLOSURE	19
RS232 CONTROL	20

PACKAGE CONTENTS

1 - LSM-S

- 1.1 - BACK PLATE
- 1.2 - BASE PANEL BRACKETS
- 1.3 - SWIVEL UNIT
- 1.4 - SCREEN MOUNT
- 1.5 - CABLE MANAGEMENT
- 1.6 - LID MOUNT BRACKETS
- 1.7 - EFA DRIVE UNIT
- 1.8 - EFA PUSH ROD ADJUSTMENT


2 - CONTROL BOX

3 - IR REMOTE

ITEMS NOT SHOWN ON PAGE

AL965 ACCESSORY PACK:

- X2 AAA BATTERIES
- MULTI-PACK OF NUTS, BOLTS AND WASHERS
- MAINS POWER, IR AND CONTACT CLOSURE LEADS



MECHANISM QUICK-START GUIDE

Some Future Automation mechanisms may ship with the control box disconnected to prevent damage during transit. In order to operate the mechanism, the control box will need to be reconnected, then have mains power applied along with the desired control method.

RECONNECTING THE CONTROL BOX

To reconnect the mechanism control box, follow the below steps:

1. Make sure the power is disconnected from the control box.
2. Remove the retaining screw and washer from the end of the control box to allow removal of the control box lid. (Image 1 Below).
3. Slide off the control box lid to reveal the control board inside.
4. Locate the green connector on the end of the loom leading from the lift mechanism. This plug will have a small tag attached stating the correct connecting socket on the control board (e.g. "AC1", "DC2"...) (Image 2 Below).
5. Plug the green connector into the corresponding socket on the control board. This plug is handed and will only connect correctly one way. Do NOT force the connector into the socket, this can cause serious damage to the control board and mechanism.
6. Route the wiring loom out of the end of the control box by inserting the black plastic inserts into the slots provided. (Image 3 Below).
7. Slide the control box cover back over the control board and replace the fixing screw and washer.



Image 1.



Image 2.



Image 3.



Image 4.

IMPORTANT

For the mechanism to operate, the green three way safety connector with the loop of wire attached, must also be plugged into the end of the control box. (Image 4 above). If this connector is not plugged in, a bright red LED will be visible inside control board and the Input Confirmation Input LED will be permanently illuminated.

INITIAL OPERATION

1


- Unpack and check the mechanism fully for any damage or obvious visual faults before operation.
- Remove all red cable ties on the mechanism before operation.

2

- Test the mechanism by running it fully up and down once (refer to the mechanism control section of the instructions for more details).

3

- Take the mount cover off by removing the button head bolts holding it in place.
- Then you can remove the cap head bolts to release the mount from the mechanism




CABINET MOUNTING

1

- Double check the cabinet measurement against the technical sheet.

2



- Raise the mechanism to its full OUT position, then place the LSM mechanism into the cabinet. Once it is central fix in place through the rear fixing holes indicated below (fixings not supplied).



LSM-BE MOUNT ASSEMBLY

1


- With the captive countersink bolts installed centre the lid mount bracket in the box enclosure and butt it up against the bottom of the lid. Fix through using appropriate fixings.



BOX ENCLOSURE FIXING


2

- Bolt the lower plate through the box enclosure.




3

- Adjust the position of the side brackets until it aligns with the captive countersink bolts in the top bracket and wind them in.



BOX ENCLOSURE AND BASE PANEL FIXING




1

- Check the Box Enclosure Joinery sizes against the correct size technical sheet.
- With the mechanism in the OUT position, lower the Box Enclosure into place

2

- Slacken clamping bolts
- Position packers between base panel and cabinet to achieve evenly spaced aperture, re-tighten when positioned.





3

- Once the position of the base panel is set, with the packers still in place fix through the brackets into the base panel (Fixings not provided).

BOX ENCLOSURE FIXING

4

- Re-attach the Mount back onto the mechanism in the same way it was removed and bolt the cover panel on top.






BOX ENCLOSURE ADJUSTMENT

1

- The LSM box enclosure bolts to the aluminium boss through slots, this allows the box enclosure to be set parallel to the cabinet when the swivel is in the home position.

2



- The LSM box enclosure can be adjusted forward or backwards to set the aperture in the down position using the two captive countersink bolts.



SCREEN MOUNTING


1

- To attach the screen the VESA plate should be attached and in the locked position first.
- One person should locate the screen in the cabinet as the other bolts through the VESA plate from the access panel.



2

- Re-install the service panel. This panel needs to be removable for screen removal and maintenance.




SWITCH ADJUSTMENTS

1

- The top switch can't be adjusted when the mechanism is in the OUT position, because the switch is active. Lower the mechanism and press STOP after about 100mm [4"]. Then adjust the OUT switch plate by loosening the bolts and sliding the switch plate up or down.


2

- The bottom switch can't be adjusted when the mechanism is in the IN position, because the switch is active. Raise the mechanism and press STOP after about 100mm [4"]. Height of the lower post determines the IN position



1

Switch Activation Surface.
Heighten post to lift in position.




CABLE ROUTING

1

- Run power and source cables through the cable management chain and then through the lifting beam, following either of the routes shown by the dotted line below.

NOTE: Conduit not supplied by Future Automation



CONTROLLING MECHANISM


IN - Takes the screen inside the cabinet

OUT - Takes the screen out of the cabinet facing forward

STOP - Stops the mechanism at any time

RESET - Screen goes to learnt position

STORE - Programs current screen position to learnt position



HOME - Takes screen to forward facing position when screen is already in an angled position

< - Rotates screen left

> - Rotates screen right

STORE + RESET - Within 1 sec stores preset position

STORE + E - within 1 sec clears right & left limit and allows the swivel to rotate 180 degree right and left


STORE + D - within 1 sec sets left limit

STORE + F - within 1 sec sets right limit

STORE + A-C - stores other positions A-C then takes it to those positions

GENERAL CONTROL

This mechanism has multiple standard control methods, each of which requires a different input method to the control box. For ease, the input sockets on the control board are labelled below.
(Control box size and style may vary to image shown)




MECHANISM EMERGENCY STOP CONNECTOR

This mechanism features an Emergency Stop Connector, which MUST be plugged into the control box in the connector labelled above for the mechanism to operate. If this connector is not plugged in, the Input Confirmation LED will be permanently lit. As per the red plastic tag attached to the Emergency Stop Connector (and shown below), the small loop of wire in this connector is designed to be replaced by a third party safety mechanism.



REPLACING MECHANISM BATTERIES

The standard Future Automation Infrared (IR) remote control required x2 AAA batteries to operate. These are provided with the mechanism in the Accessories Pack.



INFRARED (IR)

This mechanism can be controlled via the supplied 14 button Infrared (IR) Remote Control, paired with the supplied Infrared (IR) lead and sensor.

The mechanism's functions can be controlled by plugging the Infrared (IR) lead and sensor into the 3.5mm IR Input Jack shown on the General Mechanism Control page.

Confirmation of Infrared (IR) input will be shown by a single flash of the large green LED located on the end of the control box.

As Infrared (IR) control works over line of site, the Infrared (IR) sensor must be directly viewable from what ever location the remote control is being used from.

Infrared (IR) Remote Control Button Layout

IN - Brings the mechanism into the cabinet.

PRESET - Brings the mechanism to mechanism to learnt position.

STORE - Programs current mechanism position to learn position.


OUT - Brings the mechanism out of the cabinet, without swivelling.

STOP - Will stop the operation of the mechanism at ANY position.

HOME - Takes mechanism to forward facing position when swivelled.

< - Rotates mechanism left.

> - Rotates mechanism right.



STORE + PRESET - Pressed with 1 second of each other stores PRESET position.

STORE + E - Pressed with 1 second of each other clears PRESET and sets swivel 180° right and left.

STORE + D - Pressed with 1 second of each other sets left swivel limit.

STORE + F - Pressed with 1 second of each other sets right swivel limit.

STORE + A-C - Pressed with 1 second of each other stores positions A-C.

A, B, C - Brings the mechanism to mechanism to learnt position.

IMPORTANT

Only buttons indicated above are functional with the product. Any other button press will STOP the mechanism.

RADIO FREQUENCY (RF)

If purchased with the Radio Frequency (RF) control option, this mechanism can be controlled via the supplied 4 button Radio Frequency (RF) Remote Control, paired with the in-built Radio Frequency (RF) sensor.

Confirmation of Radio Frequency (RF) input will be shown by a single flash of the large green LED located on the end of the control box.

Radio Frequency (RF) control does not require line of site, but signal can be affected by cabinet thickness, cabinet material or other electronic signals (i.e. strong WIFI signals).


Radio Frequency (RF) Remote Control Button Layout

IN - Brings the mechanism into the cabinet.

OUT - Brings the mechanism out of the cabinet.

STOP - Will stop the operation of the mechanism at ANY position.

STOP - Will stop the operation of the mechanism at ANY position.



The Radio Frequency (RF) Remote Control can only be used to recall the above functions.

The mechanism limits and preset positions must be programmed using the supplied Infrared (IR) Remote Control.

IMPORTANT

Pressing any button while the mechanism is moving will STOP the mechanism.


CONTACT CLOSURE

This Mechanism can be controlled via Contact Closure, utilising an 8 Pin RJ45 Connector attached to a length of CAT5 (Type 568A or 568B) cable.


The mechanism's functions can be controlled by plugging this into the RJ45 port on the mechanism control board, then shorting pins 1-8 on this connector as shown in the Contact Closure Input Table below.

Confirmation of Contact Closure input will be shown by a single flash of the large green LED located on the end of the control box, as well as illumination of the corresponding Contact Closure LED on the printed circuit board as shown below.

RJ45 PIN LAYOUT



CONTACT CLOSURE LED LAYOUT



CONTACT CLOSURE INPUT TABLE

PIN	DESCRIPTION	ACTION
1	12V SUPPLY	12V SUPPLY - CURRENT LIMITED
2		
3	GROUND	GROUND
4		
5	DEVICE LEFT	MOMENTARY SHORT TO GROUND (PIN 3), WILL MAKE DEVICE GO LEFT.
6	DEVICE RIGHT	MOMENTARY SHORT TO GROUND (PIN 3), WILL MAKE DEVICE GO RIGHT.
7	DEVICE HOME	MOMENTARY SHORT TO GROUND (PIN 3), MAKES DEVICE GO OUT / HOME.
8	DEVICE IN	MOMENTARY SHORT TO GROUND (PIN 3), MAKES DEVICE GO IN.

WIRE/CABLE TYPE			LED INDICATOR
	568A	568B	
W	G	W	O
G		O	
W	O	W	G
B		B	
W	B	W	B
O		G	LED 3
W	BR	W	BR
BR		BR	LED 1

RS232 CONTROL

This Mechanism can be controlled via RS232, utilising a 6 Pin RJ11/RJ25 connector OR 9 Pin Serial connector attached to a length of 6 core cable.

The mechanism's functions can be controlled by plugging this into the RJ11/RJ25 port on the mechanism control box, then inputting the RS232 commands shown in the RS232 Input Table below.


Confirmation of Contact Closure input will be shown by a single flash of the large green LED located on the end of the control box.

RJ11/RJ25 PIN LAYOUT

PIN 1: TX

PIN 6: RX

PIN 3 & 4: GROUND




SERIAL PIN LAYOUT

PIN 2: RX

PIN 3: TX

PIN 5: GROUND



RS232 PROGRAMMING DETAILS

Baud Rate: 9600

Stop Bit: 1

Parity: None

Databits: 8

RJ11/RJ25	Func.	9 PIN Serial	Colour
PIN 1	TX-RX	PIN 2	Blue
PIN 3	GROUND	PIN 5	Green
PIN 4	GROUND	PIN 5	Red
PIN 6	RX-TX	PIN 3	White

RS232 INPUT TABLE

IMPORTANT - Ensure all protocols are entered exactly as written below, including Carriage Return (ENTER / ASCII 13)

Protocol	Action
fa_in Carriage Return (Enter / ASCII 13)	Device IN
fa_out Carriage Return (Enter / ASCII 13)	Device OUT with NO SWIVEL
fa_right Carriage Return (Enter / ASCII 13)	Device OUT RIGHT limit
fa_left Carriage Return (Enter / ASCII 13)	Device OUT LEFT limit
fa_preset Carriage Return (Enter / ASCII 13)	Device to PRESET memory position
fa_a Carriage Return (Enter / ASCII 13)	Device OUT to memory position A
fa_b Carriage Return (Enter / ASCII 13)	Device OUT to memory position B
fa_c Carriage Return (Enter / ASCII 13)	Device OUT to memory position C
fa_stop Carriage Return (Enter / ASCII 13)	Device STOP (At any position)
fa_home Carriage Return (Enter / ASCII 13)	Device OUT swivel parallel

NOTES:



EUROPEAN OFFICE

Address:

Unit 6-8
Brunel Road
Bedford
Bedfordshire
MK41 9TG

Phone: +44 (0) 1438 833577
Email: info@futureautomation.co.uk

Office Hours:
Mon - Fri 8:00 to 17:30 GMT
Saturday & Sunday - Closed

NORTH AMERICAN OFFICE

Address:

Enterprise Park
127 Venture Drive
Dover
NH
03820

Phone: +1 (603) 742 9181
Email: info@futureautomation.net

Office Hours:
Mon - Fri 7:00 to 17:00 EST
Saturday & Sunday - Closed