

## ADDING A SECOND SUBWOOFER TO AN ULTRASCAPE 10 or 12 SYSTEM

Follow these best practices for optimal performance when integrating a second subwoofer into an UltraScape 10 or 12 system using two D2 amplifiers in bridged mode.

**System Setup:** In this configuration, each D2 amplifier powers one side of the UltraScape system: one amplifier for the left channel, and one for the right channel.

**Amplifier Configuration:** Dedicate one D2 amplifier to be the “Master,” and other to be the “Slave.” Set the Dip Switches to the following:

**MASTER Amp**

- Full
- BT Off
- Stereo
- Bridge Off
- Master
- BT Priority

**SLAVE Amp**

- Full
- BT Off
- Stereo
- Bridge Off
- Slave
- BT Inferiority

**Signal Routing:** Connect the source to the “MASTER” D2 Amplifier using a single RCA cable, Connect one end of the RCA cable to the Coax Out (Orange) Output on the MS1, and then connect the opposite end of the same Cable to the Link In (Yellow) connection on the D2. This is a digital signal which allows for stereo playback to take place on the D2.

**\*Note:** When using the MS1, be sure to use the Coax Out then connect the other end into the Link In on the D2

