

WIRING DIAGRAM

Follow these best practices for optimal performance when setting up an UltraScape 10 or 12 system with a TruAudio D2 Amplifier.

Amplifier Configuration: Connect the Right+ wire to the Right+ terminal and the Right- wire to the Right- terminal. Repeat the same procedure for the Left channel.

Set the Dip Switches to the following:

- Full
- BT Off
- Stereo
- Bridge Off
- Master
- BT Priority

Source: Connect the source to the D2 Amplifier using RCA cables. Connect the red connector to the red input and the white connector to the white input on the D2 analog input. Connect the other ends of the RCA cables to the source's output, matching red to red and white to white.

***Note:** When using the MS.1, be sure to use the Coax Out then connect the other end into the Link In on the D2

