
Installation Instructions

MLI - Inverted Heavy Duty Lift Mechanism

Design Highlights

- -Unique Lift and Roll Flap Mechanism
- -Hand Made Quality Construction
- -Full Cable Management
- -Custom Sized to Suit Exact Size of Screen
- -Range of Add On Functions Available
- -Custom Frames for Deeper Screens and Speakers
- -Positively Driven Rack System for Secure and Robust Lifting















Safety Disclaimer

Important Safety Instructions
Explanation of graphical symbols

- -(Electric Shock Symbol) = The lightning flash within an equilateral triangle is intended to alert you to the presence of un-insulated "dangerous voltage" within the products enclosure that may be of sufficient magnitude to constitute an electric shock to persons
- -(Caution Symbol) = The exclamation point within an equilateral triangle is intended to alert you to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product
- -(Tools Symbols) = The tools symbol within a coloured square are intended to highlight the required tools necessary for correct and safe installation of the product. These are intended as a guide only, and it is at the installer's discretion as to which tools are used.

WARNING: RISK OF ELECTRIC SHOCK, ONLY AUTHORIZED INSTALLERS TO OPEN THE POWER CONTROL BOX.

WARNING: To reduce the risk of fire or electric shock, do not expose electrical parts to rain or moisture, unless the product has been specifically designed to do so.

WARNING: Failure to provide adequate structural strengthening, prior to installation can result in serious personal injury or damage to the equipment. It is the installer's responsibility to ensure the structure to which the component is affixed can support the four times the weight of the component.

WARNING: Do not exceed the weight capacity. This can result in serious personal injury or damage to the equipment. It is the installer's responsibility to ensure that the total combined weight of all attached components does not exceed that of the maximum figure stated. **WARNING:** Failure to provide adequate structural strength for this component can result in serious personal injury or damage to equipment! It is the installer's responsibility to make sure the structure to which this component is attached can support five times the combined weight of all equipment. Reinforce the structure as required before installing the component.

Warnings:

- Read all technical instructions fully before installation and use. It is the installer's responsibility to ensure that all documentation is passed on the end user and read fully before operation.
- 2. Keep all documentation.
- 3. Heed all warnings.
- 4. Follow all technical specifications and instructions during installation.
- 5. Do not use near water unless the product has been specifically designed to do so.
- 6. Clean only with a dry cloth.
- 7. Do not defeat the purpose of the polarized or grounding type plug. A polarized plug has two blades, one wider than the other. A grounding type plug has two blades and a grounding prong. The wide blade or third prong are provided for your safety. If the provided plug does not fit your outlet, consult an electrician or contact the manufacturer.
- 8. Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where the exit from the apparatus.
- Unplug the apparatus during lightning storms or when unused for long periods of time.
- 10. Only use attachments/accessories specified by the manufacturer.
- 11. Refer all servicing to qualified personnel. Servicing is required regularly on an annual basis, when the apparatus is damaged in any way, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
- 12. To completely disconnect the apparatus form the AC mains, disconnect the power cord plug from the AC receptacle on the power control box.
- 13. To prevent overheating, do not cover the apparatus. Install in accordance with the instructions.
- 14. UK, Ireland and Hong Kong only The power cord is supplied with a 13A plug having an earthing pin. The apparatus is earthed and this pin is not required for safety, merely to operate the safety shutter of mains outlet.
- 15. No naked flames such as lit candles should be placed on the unit.
- 16. Observe and follow the local regulations when disposing of batteries.
- 17. Do not expose the unit to dripping or splashing fluids.
- 18. Do not place objects filled with liquid, such as vases, on the unit.
- 19. Do not expose the batteries to excessive heat such as sunshine, fire or the like.
- For all mounted apparatus, the apparatus should be installed on solid wood, bricks, concrete or solid wood columns and battens.
- Always turn off power at source before putting on or taking off parts and cleaning.
- 22. Do not use outdoors unless marked for outdoor use.
- 23. Exceeding the weight capacity can result in serious personal injury or damage to equipment.

Future Sound & Vision trading as Future Automation intend to make this and all documentation as accurate as possible. However, Future Automation makes no claim that the information contained herein covers all details, conditions or variations, nor does it provide for every possible contingency in connection with the installation or use of this product. The information contained in this document is subject to change without prior notice or obligation of any kind. Future Automation makes no representation of warranty, expressed or implied, regarding the information contained herein. Future Automation assumes no responsibility for accuracy, completeness or sufficiency of the information contained in this document.



Contents		Page	
Introduction	Safety Information Contents	1 2	
	Contents Tool Indicator Icons	3	
Installation			
	Parts List Package Contents	4	
	Stage 1 Before You Start	5	
	Stage 2	6	
	Fixings Flap Panel to the Mechanism Stage 3		
	Fixing the Lift to the Cabinet Stage 4	7	
	Adjusting the Down Stop Position Stage 5	8	
	Positioning the Cover Infill Panel	9	
	Stage 6 Adjusting the Flap Down Position	10	
	Stage 7 Adjusting the Flap Up Position	11	
	Stage 8 Checking Screen Mount Suitability	12	
	Stage 9 Mounting the Screen to the Lift	13	
	Stage 10		
	Fixing the IR Sensor and Run the Mechanism Electrical Connections	14	
	Contact Closure IR Controls	15 16	
	RF Controls	16	
Operations		40	
	IR Control IR Operation	16 16	
	Storing Positions	17	
	Changing Batteries	17	
	RF Control RF Operation	17 17	



Contents	Page
Trouble Shooting	18
Technical Overview	19
Notes	20

Tool Indicator Icons

2. - Tape measure

1. - Drill 3. - Allen Keys 5. - Screwdrivers 7. - Pencil

Product Warranty

6. - Spanners

8. - Saw

This product carries a warranty that covers the cost of labour and spare parts incurred by any defects in materials and workmanship under normal use during a two year period from date of purchase. Support for any problems that are not hardware faults are excluded from the warranty entitlement. This warranty does not affect your statutory consumer rights.

The following is excluded from warranty service:

- Malfunctioning caused by misuse or damage, accidental or otherwise, or service modification by persons not authorised by Future Automation, or the use of any non Future Automation supplied parts;
- Any electrical, or other environmental work external to your Future Automation mechanism including power cuts, surges or lightning strikes;
- Additional items not supplied by Future Automation although they may have been supplied together by the retailer;

4. - Spirit Level

- Any 3rd party software products controlling your mechanism;
- Any transfer of ownership. Warranty is provided only to the initial purchaser;
- Compensation for loss of use of the product, and consequential loss of any kind;
- Use of the product over the specified weight capacity;
- Any damage to products during transit that is not checked and notified as "unchecked" or "damaged" upon receipt of delivery.

Any part of your system that needs to be replaced during a warranty repair becomes the property of Future Automation.



Package Contents


- 1 Mechanism
- 1.1 Flap
- 1.2 Screen Mount
- 1.3 Cable Management
- 1.4 Lifting Beam
- 2 Control Box
- 3 Remote Control

Not Shown On Page

- 4 x2 AAA Batteries
- 5 Multi Pack Of Nuts, Bolts & Washers
- 6 Mains Power & Other Leads

Nuts & Bolts Multipack:

A range of nuts, bolts, washers and spacers to help add in the mounting for your screen






















Before you Start

Check the Operation of the Mechanism.

Firstly, remove all the red cable ties which keep the mechanism safe and secure during transit. There are usually 6 ties in the locations circled on the image.

However, on some models there may be more than 6 cable ties.

Once they have all been removed, the mechanism can be powered up and tested. Connect the supplied IR remote and check that the mechanism operates correctly before continuing with the installation.




















Fitting Flap Panel to the Mechanism

The 6mm flap and the base should be made as part of the cabinet.

The surfaces of the flap should ideally be varnished or painted to help prevent it from warping.




Take care when fixing the surfaces together. Place the objects on a flat surface to make sure the edges are properly aligned when they come into contact.

Try to use as many self adhesive pads as possible to get the most secure fixture.

Use frame as a template to mark hole

locations.

Example hole locations shown above are for the Group A frame.



underside through the 2 fixing brackets on either side.

Bolt through the support frame then through base panel into the black plates on the beam using M8 x 30mm or M8 x 35mm bolts

Make sure the base panel lines up squarely, directly on top of the lifting beam.

Consult MLI TECHNICAL SHEET before fabricating any flaps or base panels.


















Fixing the Lift to the Cabinet

Place the mechanism within the cabinet. Raise the beam to the top and carfully guide the base through the opening.







With the top properly located, use the 8 pointed screws supplied, 4 on each side, to pin the mechanism in place, fixing its position left and right. These 8 screws should be screwed through the middle hole of each of the clusters of 3, shown.

With the lift fixed in position, use 8 wood screws on each side to secure the lift to the cabinet.














Adjusting the Down Stop Position


By adjusting the screw up or down, you can adjust the stop drop height of the lifting beam and also, the cover infill panel.





Make sure that the gears and racks are evenly greased and move smoothly.















Adjusting the Flap Down Position

By adjusting the white screw, at each side of the lift, you can adjust the tilt of the flap.

By loosening the M6 bolts on each side under the flap, you can adjust the position of the flap in the cabinet top. Aim for a 3mm gap all round.






CABINET BASE - PLAN VIEW



CABINET BASE - SIDE VIEW

By winding the push rods on each side, you can adjust the height of the flap in order to get it level with the cabinet top. Be sure to lock the nut securely once adjusted. Make sure the black plate doesn't touch the inside of the cabinet. This can cause strain on the motor, leading to failure.
















Adjusting the Flap Up Position















Checking Screen Mount Suitability

With a standard plasma lift, the supplied mounting type will be either a Group A or C framework, or a VESA 200 mount. Check that the type supplied suits the screen that is going to be mounted to the mechanism.


VESA 200 Mount

Remove the screen plate, and fix it to the back of the screen using the appropriate fixings.

Group A or C Framework

Remove the uprights, and fix them to the back of the screen using the appropriate fixings.

If these screen mounts are unsuitable to secure your screen, a custom mount plate can be designed.















Mounting the Screen to the Lift

Before mounting any screen, press STOP on the IR remote in order to prevent any motor movements during the mounting procedure.

Simply mount the screen on to the mount supplied with your mechanism. The example below shows a Group A framework.






The height of the inner framework is adjustable in 30mm increments. There is then the final fine adjustment available from 30mm slots in the side. The inner uprights will slide to allocate different mounting systems.

When the screen is in position, the cables can be connected and run up into the cabinet.

Pass the cables through the hole you cut in the base for the cables. Once inside the cabinet, pass the cables in to the cable management system. This resembles a black chain running from the beam to the base of the cabinet that the cables can be pushed inside to keep them tidy.
















Fix the IR Sensor and Run the Mechanism

The IR sensor can be located anywhere outside of the cabinet.





It is very important that once the mechanism is set up, the lift is run up and down a number of times to allow the straps to bed in and stabilise.


It may then be necessary to re-adjust the height and / or level of the lifting beam, as first discussed in Stage 4 of these instructions.






Contact Closure

- Use an RJ45 connector in the CCI socket on the control box to operate via contact closure



PIN DESCRIPTION		ACTION	WIRE / CABLE		CONTACT CLOSURE
PIIN	DESCRIPTION	ACTION	568A	568B	LED INDICATOR
1	12V SUPPLY	12V SUPPLY - CURRENT LIMITED	W/G	W/O	
2	12V LATCH	When 12V attached, device will go OUT. When 12V removed, device will go IN.	G	0	
3	GROUND	GROUND	W/O	W/G	
4		PIN 4 NOT USED	BL	BL	
5	DEVICE LATCH	Short to GROUND (pin 3), device will go OUT, remove short device will go IN.	W/BL	W/BL	LED 4
6	DEVICE STOP	Momentary short to GROUND (pin 3), stops device in current position.	0	G	LED 3
7	DEVICE OUT	Momentary short to GROUND (pin 3), makes device go OUT.	W/BR	W/BR	LED 2
8	DEVICE IN	Momentary short to GROUND (pin 3), makes device go IN.	BR	BR	LED 1







NOTE:

Earlier versions of the control board may not have these contact closure LED indicators.







Details

Baud rate: 9600 Stop bit: 1 Parity: None Databits: 8

RJ25		9 PIN D
PIN 1: RX	TO	PIN 2: TX
PIN 6: TX	TO	PIN 3: RX
PIN 3: GROUND	TO	PIN 5: GROUND
PIN 4: GROUND	TO	PIN 5: GROUND




IMPORTANT

Ensure protocol is entered exactly as written, including Carriage Return (Enter / ASCII 13).

Protocol	Action
fa_in Carriage Return (Enter ←)	Device IN
fa_out Carriage Return (Enter ←)	Device OUT
fa_stop Carriage Return (Enter ←)	Device STOP (At any position)

Operation Details












Operation buttons for the IR remote

In - Brings the mechanism inside the cabinet



Out - Brings the mechanism out of the cabinet facing forward

Stop - Will stop the operation at any position




Note

Only buttons indicated are functional with the product. Any button pressed when in motion mechanism will stop.

Replacing batteries



Future Automation IR Remote Controller needs x2 AAA batteries which are provided within the packaging



















Inverted Heavy Duty Lift Mechanism - Trouble shooting guide

Lift Mechanism MLI - Trouble shooting

For information on our products please refer to our web site www.futureautomation.co.uk or for questions on installations and our product range please phone us on - +44(0) 1438 833577 and ask for our technical support department



















Technical Overview


A general technical overview of the MLI lift mechanism

	MLI	
Product Dimensions	Custom	
Weight	Custom	
Power Consumption	250W - 500W	
Power Consumption On Standby	100mA	
Lifting Capacity (Kg)	50Kg [110.2lb]	
Standard Screen Mount Colour	Black	
	Width - N/A	
Max Television Size	Height - N/A	
	Depth - 155mm [6.1"]	
Control	IR Remote, RF Remote, Contact Closure & RS232	
Power Supply	240V or 110V	
Control Of 3rd Party Product	Yes	
Output Power Supply	Yes (12V)	
Control Box Size (W,D,H)	152x200x55mm [6x7.9x2.2"]	
Shipping Details		
Dimensions Approx (M.D. L.)	1800x500x1200mm	
Dimensions Approx (W,D,H)	[70.9x19.7x47.2"]	
Weight Approx (Kg)	50 - 60Kg [110.2 - 132.3lb]	











Future Automation

Unit 2 Kimpton Enterprise Park Claggy Road Kimpton Hertfordshire SG4 8HP United Kingdom

Tel: +44 (0) 1438 833 577 Fax: +44 (0) 1438 833 565

Email: info@futureautomation.co.uk

www.futureautomation.co.uk